RM24918
RM84918

Universal Remote Instruction Manual

Table of Contents

Setup 3
- Battery Installation 3
- Battery Saver 3
- Code Saver 3
- Code Setup 3

Button Functions 4
- DVD Functions 6
- SAT Functions 7

Code Entry 8
- Direct Code Entry 8
- Code Search 9

Using Your Remote 10
- Code Identification 10
- Controlling Devices with Power On and Off 11
- Controlling Combo Devices 11
- VCR/DVD/DVR Punch-Through 11
- Volume/Mute Control and Punch-Through 12
- All Volume/Mute Control to any one Mode 12
- Setting any Mode for its own Volume/Mute 13

Troubleshooting 14

Congratulations on your purchase of the RM24918 Universal Remote Control. The RM24918 is one of the most easy to use remote controls available today. With the RM24918, juggling multiple remote controls is a thing of the past! Your RM24918 controls up to six devices, including the most popular brands of TV, VCR, DVD, SAT, CBL, and audio equipment.

The RM24918's **BACKLIGHT** button lights up the remote's buttons, which stay lit until 5 seconds after you stop pressing buttons.

Note: Some functions from your original remote may not be controlled by this remote. Use the original remote, if available, to control such functions. Sometimes buttons other than described in these instructions may actually perform the function. For example, the CHAN and VOL buttons might be used to navigate through menu choices. We recommend you experiment with the remote to identify if such situations pertain to your equipment.

Setup

Battery Installation

1. On the back of the remote, push down on the tab and lift the cover off.
2. Match the batteries to the + and - marks inside the battery case, then insert 2 AAA Alkaline batteries.
3. Press the battery cover back into place.

Battery Saver

Your remote automatically turns off if the buttons are depressed more than 30 seconds. This will save your batteries should your remote get stuck in a place where the buttons remain depressed (e.g., between the sofa cushions).

Code Saver

You will have up to 10 minutes to change the batteries in your remote without losing codes you have programmed. However, do not press any buttons until batteries are installed in the remote. If buttons are pressed without batteries in the remote, all codes will be lost.

Code Setup

The **CODE SEARCH** button is used to setup the remote. You can either setup the remote using the code for your brand of product, from the code tables (on separate sheet), or you can search through the library of codes until you find a code that works for your product. Please refer to "Programming with Code Search" page 9 for more information on using the code search feature to learn how to search through the library of codes for your products.
NOTE: You can store any kind of code under any mode (except TV). I.E. you can store a VCR code under the **CBL/SAT** button, or a DVD code under the **VCR** button, etc. However, you can only store TV codes under the **TV** button.

Button Functions

Some buttons on the remote might have functions that are referred to by different names on the device you are controlling. E.G. **PREV.CH** may be called RECALL, or **ENTER** may be called DISPLAY. These differences depend on the brand and model of your product. Also, this remote can only operate features that exist on your product. E.G., your product must have **PREV.CH** ability for the **PREV.CH** button to operate this feature.

TV, VCR, etc. Selects product to be operated.

CODE SEARCH For setup.

Red Indicator Lights when any button is pressed.

INPUT For some TVs, press repeatedly to select from available viewing sources (antenna, cable box, VCR, etc.).

PREV.CH Returns to the previously selected channel, or DVD repeat toggle. **REPEAT** performs DVD players "A-B Repeat" (or RPT A.B) function for repeat play of current Chapter or Track.

RECORD, PLAY, STOP, REW, FF, PAUSE VCR control buttons operate your VCR even when the remote is set to operate the TV. Also operates DVD Scan -/+. Note the VCR keys also control DVD when in DVD Mode.

ENTER For some TV models, used after direct channel number entry to immediately change to the selected channel.

MENU Selects the on-screen menu.



GUIDE displays satellite or cable on-screen program guide.

Button Functions, cont.

Turns **Backlight** on and off.

ON•OFF Turns product On or Off.

CHANNEL Up/Down Changes the channels **TRACK +/-** controls DVD/CD track selection i.e. DVD/CD Track Skip Up/Down (in DVD and CD modes).

INFO/DISPLAY button brings up DVD Display or Control Menu for Chapter/ Track/Title number, Time remaining/elapsed indication, system information, etc.

VOLUME UP/DOWN Changes the volume level of the product, normally the TV.

CC (SUBTITLE) TV Closed Caption (if your TV has this feature) or DVD Subtitle toggle.

MUTE Turns off the TV sound while the picture remains.

NUMBERS Enter numbers for direct channel selection. Some products require ENTER to be pressed after channel selection.

OK Selects menu items for the device you are controlling.



RESUME, AUDIO, ZOOM, ANGLE, TITLE Controls DVD functions.

Note: The **REC** button must be pressed TWICE to record from your VCR. For some brands of VCRs, you might need to press the **REC** button once, then press it again for three seconds.

DVD Functions

This remote has several dedicated buttons used for DVD functions. The descriptions may vary from your original remote descriptions.

SCAN+ and **SCAN-** buttons control the speed of Fast Forward and Reverse Playback respectively.
SKIP (Channel Up & Down) buttons respectively locate the succeeding or preceding Chapters or Tracks on a disc.
SUBTITLE (CC) Turns the subtitles on or off.
TITLE Brings up the DVD Title Menu screen.
REPEAT A-B button performs DVD players "A-B Repeat" (or RPT A.B) function for repeat play of current Chapter or Track.
INFO/DISPLAY button brings up DVD Display or Control Menu for Chapter/Track/Title number, Time remaining/elapsed indication, system information, etc.
MENU brings up the DVD disc Menu screen - use with the **UP**, **DOWN**, **LEFT** & **RIGHT** navigation buttons.
OK button is used for on-screen Menu selection. Note some DVD players require the Play button to be used.
EXIT Exit On-Screen Menus and/or Return to previous On-Screen selection.
PLAY button is used to start Disc playback and for Menu selection on some DVD players.
STOP button stops Disc playback.
PAUSE button pauses Disc playback - press PLAY to resume.
OPEN/CLOSE Opens or closes the disc tray.
+10 Use with digit keys to select tracks greater than 10.
GUIDE/PROG Program the playback order of chapters or tracks on your disc.
AUDIO selects the audio language or sound during disc playback.
SETUP/INPUT brings up the DVD Players Setup Menu.
RESUME Continues disc playback from where you stopped (if supported by your DVD player).
ANGLE selects the viewing angle during disc playback.
ZOOM Zoom or enlarge a specific area of the screen.
Note, not all DVD Players support all the functions described above.

SAT Functions

GUIDE/PROG button displays on-screen Satellite Channel Guide.
CHANNEL+ and **CHANNEL-** buttons perform the "**Page+**" and "**Page-**" function for on-screen Guide Menus used by some Satellite systems.
INFO/DISPLAY button brings up Satellite Display screen for current Channel and system information.
MENU brings up the Satellite Menu screen - use with the **UP**, **DOWN**, **LEFT** & **RIGHT** navigation buttons.
OK button is used for on-screen Menu selection.
EXIT button is used to Exit or Clear on-screen Menu displays.
INPUT/SETUP button performs the Satellite TV/SAT function.

Direct Code Entry

1. Press and hold the **CODE SEARCH** button until the red indicator stays on, then release the **CODE SEARCH** button.

2. Press and release the desired mode button (**TV**, **VCR**, etc.). The red indicator blinks, then stays lit.

3. Enter the 3 digit code from the code tables (on separate sheet). Note: after a valid code entry, the red indicator turns off. For an invalid code, the red indicator flashes.



4. With your device on, press **ON•OFF**. If the device turns off, no further programming is required. Note: If some buttons do not operate your equipment, try one of the other codes for your brand.

Write your codes down here for easy reference later.

Device	Device stored	Code
TV	TV	
DVD		
VCR		
CBL/SAT		
AUDIO		
AUX		

Code Search

If your device does not respond after you have tried all the codes for your brand, or if your brand is not listed, try searching for your code by following these steps.

1. Manually turn on the device (**TV**, **VCR**, etc.) to be controlled.

2. Press and hold the **CODE SEARCH** button until the red indicator stays on, then release the **CODE SEARCH** button.

3. Press and quickly release the desired mode button (**TV**, **VCR**, etc.). The red indicator blinks off once.

4. Press the **ON•OFF** button repeatedly (up to 300 times) until the device to be controlled turns off. The red indicator blinks off with each button press.

5. Press and release **ENTER** to install the code.

Most users will store VCR codes under the **VCR** button, Cable codes under **CABLE**, etc. If (for example) you want to store a VCR code under **CABLE**, first follow the procedure for Direct Code Entry (page 8) and press **CABLE** in step 2 of Direct Code Entry, then enter ANY VCR code in step 3 of Direct Code Entry. Then follow the steps above for Code Search.

Note: If the device does not have a **CHANNEL UP** button, use **PLAY** (VCR only) or **POWER** instead. Code Search starts from the currently stored three digit number under that mode. Sometimes the first code that "works" with your device may only allow limited functionality (e.g. the MENU button might not work). There may be a code that performs more functions. Continue the code search process until the best code is found.

Code Identification

The Code Identification Feature allows you to identify the three digit library code stored under your device key. For example, if you want to find out what three digit code is stored under your TV device key, follow the six steps below:

1. Press and hold the **CODE SEARCH** button until the red indicator stays on. Release the **CODE SEARCH** button.

2. Press and release the desired mode button (**TV**, **VCR**, etc.). The red indicator blinks, then stays lit.

3. Press and release the **CODE SEARCH** button. The red indicator blinks once and remains lit.

4. To find the first digit for the code stored under the mode key pressed in step 2, press each numeric key from **0-9** in turn. The number that causes the indicator light to blink is the first digit in your code.



5. To find the second digit, repeat step 4.

6. Repeat step 4 again to find the third digit. This time the red indicator turns off and stays off.

Controlling Devices with Separate Power On and Off Buttons

Some GE, RCA and ProScan models require you to press the device button for more than one second to turn the device on and the **POWER** button to turn the device off.

Controlling Combo Devices

Some Combo devices (e.g. TV/VCR, TV/DVD, DVD/VCR, etc.) will require you to set up two different Mode buttons to control both parts of the Combo device. For example, if you have a TV/DVD Combo, you might need to set up one code under the **TV** button to control the TV part AND a separate code (under any other Mode button) to control the DVD part.

VCR/DVD Punch-Through

This remote allows the 6 VCR transport buttons (i.e. **PLAY**, **PAUSE**, **STOP**, **FF**, **REWIND**, and **REC**) to Punch-Through control from any Mode programmed with TV, SAT or Cable codes to the last **VCR**, or **DVD** programmed Mode you used. This feature will not operate if the programmed TV, SAT or Cable code has its own VCR transport button control e.g. a TV Combo, SAT/PVR, etc.

Volume/Mute Control and Punch-Through

This remote lets you select which device Mode controls your Volume/Mute buttons. The remote is initially set for all device Modes to use their own Volume/Mute control if present. If the programmed code has no Volume/Mute operation of its own then those buttons will punch-through control to the **TV** Mode device without needing to change to **TV** Mode.

Any Mode chosen for Volume/Mute control MUST have its own Volume/Mute function or the Volume/Mute buttons will do nothing.

Setting ALL Volume/Mute Control to any one Mode

This routine can set all Modes to “punch-through” to any one chosen Mode for Volume/Mute button control without the needing to change to that Mode.

1. Press and hold the **CODE SEARCH** button until the red indicator turns on, then release the button.

2. Press and hold the **MUTE** button until the red indicator blinks off, then release the button.

3. Press and release the desired Mode button (**TV**, **VCR**, etc.) for Volume/Mute control, the red indicator blinks then stays on.

4. Press and release the **MUTE** button and the red indicator turns off. The red indicator will blink rapidly for three seconds if the Mode you have selected has no Volume/Mute control.

All other Modes will now punch-through to your chosen Mode for Volume/Mute control.

Setting any Mode to use its own Volume/Mute Control

This routine can set any Mode to use only its own Volume/Mute control. Note - If your chosen Mode has no Volume/Mute functions of its own then the Volume/Mute buttons will do nothing.

1. Press and hold the **CODE SEARCH** button until the red indicator turns on, then release the button.

2. Press and hold the **MUTE** button until the red indicator blinks off, then release the button.

3. Press and release the desired Mode button (**TV**, **VCR**, etc.), the red indicator blinks then stays on.

4. Press and release the **VOLUME-** (Down) button, the red indicator blinks then stays on.



5. Press and release the **MUTE** button and the red indicator turns off.

Your chosen Mode will now use its own Volume/Mute control.

Troubleshooting

Remote does not operate your product.

- Press the mode button of the product you want to control.
- Program the remote with a new code.
- Install new batteries. (You might have to reprogram your remote after installing new batteries.)
- Remote may not be compatible with your product.

Remote does not operate some features of your product.

- Sometimes a particular code might operate some features but not all. Try programing remote with a new code.
- Remote may not be able to operate all features of your product or button names might be different than your product.

Red Indicator blinks after you program a product code.

- Remote did not accept the code.
- Try to program the code again or try a different code.

Lost Your Codes?

Enclosed with this remote is a sticker on which you should write the codes for each device you programmed. Apply the sticker to the back of the remote or somewhere convenient for future reference.

Also on the sticker is our website address which, should you lose your codes or programming instructions, you can find available on our website: www.jascoproducts.com

90 Day Limited Warranty

Jasco Products Company warrants this product to be free from manufacturing defects for a period of ninety days from the original date of consumer purchase. This warranty is limited to the repair or replacement of this product only and does not extend to consequential or incidental damage to other products that may be used with this unit. This warranty is in lieu of all other warranties express or implied. Some states do not allow limitations on how long an implied warranty lasts or permit the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific rights, and you may also have other rights which vary from state to state. If unit should prove defective within the warranty period, return prepaid with dated proof of purchase to:

Jasco Products Company
311 N.W. 122nd
Oklahoma City, OK 73114

RM24918
RM84918

Universal Remote
Instruction Manual

Jasco Products Company
311 N.W. 122nd
Oklahoma City, OK 73114

Made in China

RM24918-07/05